



Looped Monitors




Code=1, DIP 1 & 6 = on



Code=1, DIP 1 = on



Code=1, DIP 1 = on



Code=1, DIP 1 = on



Slave 3




Slave 2





Slave 1



Master



BUS PL S+ S-



220~240VAC



Please see page 15 of the video monitor manual for the setting of SLAVE Monitors

Please see page 17 of the video monitor manual for the setting of PANEL ON for monitors to display the visitor image